



VIKING ARM®

The Original



Viking Arm

Jack 46800A

EN


Manual (Original)

DE

Handbuch

Single-handed lifting and clamping tool


Einhand-Hebe- und Klemmwerkzeug

AEN
DE

B

EN

DE



6 Nm /
4.4 ft lb




18

19

C

EN


DE

**D****E**

F

EN

DE



**Save all warnings and
instructions for future reference**

	READ the instruction manual before use. Keep for future reference. Paper copy available free of charge on request: support@vikingarm.com
---	---

Explanation of Warning Symbols

	CAUTION: Minor or moderate injury may occur due to potential hazards.
	CAUTION: Minor or moderate injury may occur due to crushing hazards.
	CAUTION: Minor or moderate injury may occur due to pinching or compression hazards.
	CAUTION: Minor or moderate injury may occur if the product tips over.
NOTICE	Identifies a situation that, if not avoided, may result in property damage .

Information for safe use

- Read and follow all safety warnings, instructions, illustrations, and specifications supplied with the Product
- Do not exceed the specified load limit
- Never press the No-Load Full Release Button (3) while the Product is under load
- Always wear safety footwear
- The use of protective eyewear and gloves is recommended for safety
- If the load is unstable, use additional Products for support
- Ensure the load is always in full contact with the Lifting Bars (14)
- Never place any part of your body under the Lifting Bars (14) when the Product is under load
- Use the Product only on level surfaces to avoid tipping
- Always center the load on the Lifting Bars (14) before operation
- Use only original Viking Arm parts and accessories
- Keep children and pets clear of the work area

Viking Arm The Original single-handed lifting and clamping tool

In this manual, "Viking Arm The Original" is hereinafter referred to as the "Product".

Components shown - See A and B

- 1. Top-stop Screw
- 2. Incremental Release Button
- 3. No-Load Full Release Button
- 4. Lock & Release Unit ("Brake")
- 5. Fixed handle
- 6. Operating Lever
- 7. Max load info
- 8. Mounting holes
- 9. Base Pad
- 10. Product name and number
- 11. QR-code to this manual
- 12. Manufacturer info
- 13. CE marking
- 14. Lifting Bars
- 15. Pinching area and warning sign about potential pinching/crushing.
- 16. Lifting plates
- 17. Shaft
- 18. Screws 6 x M5x16
- 19. Hex key (Allen key) 3 mm
- 20. Year and month of manufacture:
number = year of production,
dots = month of production



CAUTION: Risk of pinching

Minor or moderate injury may occur if fingers or hands are caught between moving parts during lifting or lowering.

- Never place fingers or hands in the Pinching Point where there are moving parts (15)
- Keep all body parts away from moving components (e.g., spiral spring, Lifting Plates (16))



CAUTION: Risk of tipping over

Minor or moderate injury may occur if the Product tips over due to an unstable load or if the specified load limit is exceeded.

- Do not exceed the specified load limit
- Always secure the lifted load to prevent tipping
- Use additional Products if necessary

Intended use

- The Product enables lifting, spreading and clamping with precision within the weight limits specified in Technical Data
- The Product must not be used to support permanent installations
- The Product must not be used to secure cargo during transport
- The Product must not be used to lift people

Assembly and preparing

- Assemble the Product as shown in B
- Always check the Product for proper working and damage before use
- Check that all the screwed elements are firmly in place
- Check that the Lifting Bars (14) and Base Plate (9) are level. If either part is not level, replace the part.
- Never modify the Product or any part of it

Markings on product A

The following markings are shown on the Product

- QR code to this manual. Read instructions first (11)
- Max load (7)
- Product name and number (10)
- Manufacturer info (12)
- CE marking (13)
- Year and month of manufacture (20)
- Pictogram CAUTION (15): Risk of pinching at the pinch point area involving the spiral spring and friction plates (16).

The symbol also serves as a reminder that there is a risk of crushing if any part of the body is positioned under the load in the event of product malfunction, load slippage, or unintended activation of the No-Load Full Release Button (3).

Operation

Lifting



CAUTION: Risk of crushing

Minor or moderate injury may occur if a lifted load slips, if the Product malfunctions, or if the No-Load Full Release Button (3) is pressed unintentionally.

- Always secure the lifted load to prevent it from falling
- Always check that the Product is in working order before use
- Never place any part of your body under the load or the Lifting Bars (14) while the product is in use
- Never press the No-Load Full Release Button (3) while the Product is supporting a load

To lift C:

- Place the Lifting Bars (14) under the load, ensuring the Base Plate (9) rests firmly on a level, solid surface
- Grasp the Fixed Handle (5) and squeeze the Operating Lever (6) towards it
- Release the Operating Lever (6)
- Repeat the action until the desired height is reached

Lowering



CAUTION: Risk of crushing

Minor or moderate injury may occur if any part of the body is placed under the load or the Lifting Bars (14) during lowering.

- Never place any part of the body under the load or the Lifting Bars (14) during lowering or while the product is in use
- Never press or activate the No-Load Full Release Button (3) while the Product is supporting a load



CAUTION: Risk of pinching

Minor or moderate injury may occur if fingers or hands are caught between moving parts during lifting or lowering.

- Never place fingers or hands in the Pinching Point where there are moving parts (15)
- Keep all body parts away from moving components (e.g., spiral spring, Lifting Plates (16))

To lower the load **D**:

- Press the Incremental Release Button (2) repeatedly to lower the load
- For high precision, press the Incremental Release Button (2) slowly and partially

For rapid lowering of the lifting bars (14), ensure that **no load** is applied to the lifting bars.

If a load is present, secure the load first and use the Incremental Release Button (2) to control the lowering process until the load is fully supported and the product is unloaded. **The No-Load Full Release Button (3) may only be activated once the lifting bars are completely free of load.**

- Press and hold the No-Load Full Release Button (3) while pressing the handle down **A E**

NOTICE: Risk of damage to the property

Property damage may occur if the load slips, tips over, if the Product malfunctions, or if the No-Load Full Release Button (3) is pressed unintentionally.

- Always secure the lifted load
- Always check that the Product is in working order before use
- Never press the No-Load Full Release Button (3) while the Product is under load.
- Do not exceed the specified load limit
- Use protective material to prevent damage to sensitive surfaces.

Securing the Product

The Product can be secured to a solid surface, such as a workbench or countertop.

- Use three appropriately sized screws (not included).
- Fasten the Product through the Mounting Holes (8)

Service and Maintenance

- Check the Product at regular intervals for damage and to ensure proper function of all moving parts
- Do not use the Product if damaged
- Clean components before and after use
- Regular lubrication is recommended for optimal performance
- Use a fine, high-quality mineral oil (e.g., mineral oil for air-powered tools)
- Never use thick oil, motor oil, waste oil, or oil containing silicone
- Wipe the Shaft (17) with a clean rag
- Apply a few drops of oil on both narrow sides of the shaft (17) as shown in the illustration **F**
See also video <https://shorturl.at/8Ubvh>
- Spread the oil by sliding the Product's body up and down the Shaft (17)
- Wipe off any excess oil with a clean, dry rag

Troubleshooting

Not lifting

If you pump the Lever (6) and the Lifting Bars (14) do not move up, the Lifting Plates (16) may be stuck together and require cleaning Solution: See video here

https://www.youtube.com/watch?v=z_MSdBJ2aXc

- Remove the Lifting Plates (16)
- Wipe the Shaft (17) and the Lifting Plates (16) with a clean rag
- Apply a small amount of fine mineral oil to the Lifting Plates (16), then wipe clean again
- When reassembling, ensure that all three Lifting Plates (16) have the cut-off corner facing the 5 o'clock position (imagine holding the Product in front of you by the handle)
- After assembly, apply a few drops of oil into the Lock & Release Unit as shown in fig. **F**

Not holding the weight

- If the Lifting Bars (14) move up normally when you press the Operating Lever (6) but drop down again when released, or if the Product is unable to hold the load, the issue is with the Lock & Release Unit (4)
- Do not use the Product until it has been repaired
- Contact us at vikingarm.com/support for assistance

Support

For support, contact your dealer or visit vikingarm.com/support — we're here to help!

Warranty

Limited Lifetime Warranty

We are pleased to offer a comprehensive Limited Lifetime warranty for our Viking Arm® – The Original. The warranty is to provide our valued customers with peace of mind and assurance in the quality and durability of our product. This warranty reflects our commitment to excellence and customer satisfaction.

Warranty Coverage

Viking Arm will, at its sole discretion, repair or replace, without charge, any defects due to faulty materials or workmanship for any **Viking Arm – The Original purchased on or after October 1, 2024**. Proof of purchase required. The customer may be requested to perform easy repairs him/herself with help from a Viking Arm representative. This warranty does not cover part failure due to normal wear and tear or tool abuse. Proper care and maintenance as outlined in the user manual must be followed.

Exclusions

Viking Arm reserves the right to reject warranty claims for products purchased from unauthorized sellers, including unauthorized internet sellers, unless prohibited by law. This warranty does not apply to normal wear-and-tear, damage caused by improper usage, or damage caused by attempted repairs.

EXCEPT WHERE PROHIBITED BY LAW, VIKING ARM EXPRESSLY DISCLAIMS ANY OTHER EXPRESS OR IMPLIED WARRANTY OF ANY KIND, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, WHETHER ARISING BY LAW, CUSTOM, CONDUCT, USAGE OR TRADE.

VIKING ARM SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES.

How to Obtain Warranty Service

Reach out to our customer service team via the store you bought the product from or fill out the support request form at our webpage <https://www.vikingarm.com/support-inquiry>.

Older Viking Arms and all other products have 2-year warranty. But you are always welcome to contact us outside the warranty period if you have a problem with any Viking Arm products. We will do our best to help!

Technical data

Specifications

- Recommended max. load: up to 150 kg / 330 lb
- Operation range (without shaft extender): 6-215 mm / 0.24 - 8.5 in
- Dimensions: Height 383 mm / 15.08 in. Length: 219 mm / 8.6 in. Width: 104 mm / 4.1 in
- Standard base plate: 6 x 105 x 87 mm / 0.24 x 4.13 x 3.43 in
- Weight: 1.43 kg / 3.1 lb

EU Declaration of Conformity

EU DECLARATION OF CONFORMITY		Original
Manufacturer:		
Name:	Viking Arm AS	
Address:	Lommedalsveien 230 N-1353 Bærum Verk Norway	
Product Name:	Viking Arm (Jack) 46800A	
Type:		
This declaration of conformity is issued under the sole responsibility of the manufacturer. The object of the declaration described above is in conformity with the relevant Community harmonisation legislation.		
General applicable directives: Machinery Directive 2006/42/EC		
Standard Applied: EN ISO 12100 Safety of machinery, Basic concepts EN ISO 13857 Safety of machinery, Safety distance		
The party authorised to compile the technical file: Name: Lidek Berdychowski Position: CTO		
Signature: 		
Name: Ulf Atle Hans Position: CEO		
Place and date of issue: Bærum Verk on 26.08.2025		
Viking Arm AS info@vikingarm.com	Lommedalsveien 230 www.vikingarm.com	N-1353 Bærum Verk Norway

Available accessories

(www.vikingarm.com/products)

- 3 mm Base Plate
- 6mm XL Base Plate
- Base Pad for standard Base Plate
- Lifting Pad
- Cabinet Installation Kit
- Clamp Lock
- Shaft Extender (for clamping only)
- DK 2 Decking Kit
- DK 4 Decking Kit
- Lifting Cradle (adapter for use with a suction cup)

Other information

See product in use



Disposal

Old products and parts must not be disposed of with normal household waste. Dispose of the Product responsibly in accordance with applicable local regulations. As a certified Eco-Lighthouse company, we encourage environmentally responsible recycling and disposal of tools and components. Whenever possible, deliver metal and plastic parts to appropriate recycling facilities.

Bewahren Sie alle Warnhinweise und Anweisungen für späteres Nachlesen auf

	LESEN Sie die Bedienungsanleitung vor der Verwendung. Für zukünftige Verwendung aufbewahren. Gedruckte Version kostenlos auf Anfrage: support@vikingarm.com
---	---

Erläuterung der Warnsymbole

	ACHTUNG: Leichte oder mittelschwere Verletzungen können durch potenzielle Gefahren auftreten.
	ACHTUNG: Leichte oder mäßige Verletzungen können durch Quetschgefahren entstehen.
	ACHTUNG: Leichte oder mäßige Verletzungen können durch Klemm- oder Kompressionsgefahren entstehen.
	ACHTUNG: Leichte oder mäßige Verletzungen können entstehen, wenn das Produkt umkippt.
HINWEIS	Leichte oder mittelschwere Verletzungen können durch potenzielle Gefahren auftreten.

Informationen zur sicheren Verwendung

- Lesen und befolgen Sie alle Sicherheitshinweise, Anweisungen, Abbildungen und Spezifikationen, die mit dem Produkt geliefert werden.
- Überschreiten Sie nicht die angegebene Belastungsgrenze.
- Drücken Sie niemals die Bedientaste für die vollständige Freigabe (3), während das Produkt belastet ist.
- Tragen Sie stets Sicherheitsschuhe.
- Das Tragen einer Schutzbrille und von Schutzhandschuhen wird aus Sicherheitsgründen empfohlen.
- Achten Sie stets auf eine sichere und stabile Abstützung der Last und sichernd Sie die Last gegebenenfalls durch weitere Maßnahmen.
- Stellen Sie sicher, dass die Last stets vollständigen Kontakt mit der Hubgabel (14) hat.
- Lassen Sie niemals zu, dass sich Körperteile unter den der Hubgabel (14) befinden, wenn das Produkt belastet ist.
- Verwenden Sie das Produkt nur auf ebenen Flächen, und achten Sie auf einen sicheren Stand des Werkzeugs, um ein Umkippen zu vermeiden.
- Zentrieren Sie die Last vor dem Betrieb immer auf den der Hubgabel (14).
- Verwenden Sie nur Originalteile und -zubehör von Viking Arm.
- Halten Sie Kinder und Haustiere vom Arbeitsbereich fern.

Viking Arm® – Das Original Einhand-Hebe- und Klemmwerkzeug

In diesem Handbuch wird „Viking Arm® The Original“ nachfolgend als „Produkt“ bezeichnet.



Abgebildete Komponenten – siehe A und B

1. Anschlagschraube
2. Bedientaste für die schrittweise Entlastung
3. Bedientaste für die vollständige Freigabe
4. Verriegelungs- und Freigabemechanismus („Bremse“)
5. Fester Griff
6. Bedienhebel
7. Angaben zur maximalen Belastung
8. Befestigungslöcher
9. Grundplatte
10. Produktname und -nummer
11. QR-Code zu dieser Anleitung
12. Herstellerangaben
13. CE-Kennzeichnung
14. Hubgabel
15. Quetschbereich und Warnschild über mögliche Quetsch- und Klemmgefahren
16. Hebeplatten
17. Führungsstange
18. Schrauben 6 x M5x16
19. Sechskantschlüssel (Inbusschlüssel) 3 mm
20. Herstellungsjahr und -monat
Zahl = Produktionsjahr,
Punkte = Produktionsmonat

Bestimmungsgemäße Verwendung

- Das Produkt ermöglicht präzises Heben, Spreizen und Klemmen innerhalb der in den technischen Daten angegebenen Gewichtsgrenzen.
- Das Produkt darf nicht zur dauerhaften Abstützung von festen Konstruktionen verwendet werden.
- Das Produkt darf nicht zur Sicherung von Ladungen während des Transports verwendet werden.
- Das Produkt darf nicht zum Heben von Personen verwendet werden.

Montage und Vorbereitung

- Montieren Sie das Produkt wie in B dargestellt.
 - Überprüfen Sie das Produkt vor dem Gebrauch stets auf ordnungsgemäße Funktion und Beschädigungen.
 - Vergewissern Sie sich, dass alle verschraubten Elemente fest sitzen.
 - Überprüfen Sie, ob die Hubgabel (14) und die Grundplatte (9) gerade und planeben sind. Sollte eines der Teile verbogen oder beschädigt sein, ersetzen Sie es bitte.
- Nehmen Sie keine Veränderungen am Produkt oder an Teilen davon vor.

Kennzeichnungen auf Produkt A

Die folgenden Kennzeichnungen sind auf dem Produkt angebracht

- QR-Code zu dieser Anleitung. Bitte lesen Sie zuerst die Anweisungen (11)
- Maximale Belastung (7)
- Produktname und -nummer (10)
- Herstellerangaben (12)
- CE-Kennzeichnung (13)
- Herstellungsjahr und -monat (20)
- Piktogramm ACHTUNG (15): Gefahr des Einklemmens im Quetschbereich mit der Spiralfeder und den Reibplatten (16).
Das Symbol weist außerdem darauf hin, dass eine Quetschgefahr besteht, wenn sich im Falle einer Fehlfunktion des Produkts, eines Lastabrutschens oder einer unbeabsichtigten Betätigung der No-Load-Full-Release-Taste (3) ein Körperteil unter der Last befindet.

Betrieb

Heben



ACHTUNG: Klemmgefahr

Geringe oder mittlere Verletzungen können auftreten, wenn eine angehobene Last verrutscht, das Produkt eine Fehlfunktion aufweist oder die No-Load Full Release Taste (3) unbeabsichtigt betätigt wird.

- Sichern Sie die angehobene Last stets, um ein Herunterfallen zu verhindern.
- Überprüfen Sie vor jedem Gebrauch, ob das Produkt funktionsfähig ist.
- Lassen Sie niemals zu, dass sich während des Gebrauchs des Produkts Körperteile unter der Last oder den Hubgabel befinden (14).
- Betätigen oder aktivieren Sie die No-Load Full Release-Taste (3) niemals, solange das Produkt eine Last trägt.



ACHTUNG: Quetschgefahr

Geringe oder mittlere Verletzungen können auftreten, wenn Finger oder Hände während des Hebens oder Absenkens zwischen bewegliche Teile geraten.

- Legen Sie niemals Finger oder Hände in den Quetsch- bzw. Klemmbereich, in dem sich bewegliche Teile befinden (15).
- Halten Sie alle Körperteile von beweglichen Komponenten fern (z. B. Spiralfeder, Hebeplatten (16)).



ACHTUNG: Kip gefahr

Geringe oder mittlere Verletzungen können auftreten, wenn das Produkt aufgrund einer instabilen Last kippt oder die angegebene Traglast überschritten wird.

- Überschreiten Sie nicht die angegebene Belastungsgrenze.
- Sichern Sie die angehobene Last stets, um ein Umkippen zu verhindern.
- Ergreifen Sie bei Bedarf weitere Maßnahmen, um die Last stabil abzustützen und zu führen, um ein Kippen zu verhindern.

HINWEIS: Gefahr von Sachschäden.

Sachschäden können auftreten, wenn die Last verrutscht oder kippt, das Produkt eine Fehlfunktion aufweist oder die No-Load Full Release Taste (3) unbeabsichtigt betätigt wird.

- Sichern Sie die angehobene Last immer.
- Überprüfen Sie vor jeder Verwendung, ob das Produkt ordnungsgemäß funktioniert.
- Drücken Sie niemals die Leerlauf-Schnell löstaste (3), wenn das Produkt unter Last steht.
- Überschreiten Sie niemals die angegebene Traglast.
- Verwenden Sie geeignete Schutzmaterialien, um Schäden an empfindlichen Oberflächen zu vermeiden.

Zum Anheben C:

- Positionieren Sie die Hubgabel (14) unter der Last und stellen Sie sicher, dass die Grundplatte (9) fest auf einer ebenen, stabilen Oberfläche aufliegt.
- Fassen Sie den festen Griff (5) und drücken Sie den Bedienhebel (6) in dessen Richtung.
- Lassen Sie den Bedienhebel (6) los.
- Wiederholen Sie diesen Vorgang, bis die gewünschte Höhe erreicht ist.

Absenken



ACHTUNG: Klemmgefahr

Geringe oder mittlere Verletzungen können auftreten, wenn während des Absenkens Körperteile unter der Last oder den Hubarmen (14) positioniert werden.

- Platzieren Sie während des Absenkens oder der Verwendung des Produkts niemals Körperteile unter der Last oder den Hubarmen (14)
- Betätigen oder aktivieren Sie die No-Load Full Release Taste (3) niemals, solange das Produkt eine Last trägt



ACHTUNG: Quetschgefahr

Geringe oder mittlere Verletzungen können auftreten, wenn Finger oder Hände während des Hebens oder Absenkens zwischen bewegliche Teile geraten.

- Finger und Hände dürfen nicht in die Quetschstellen mit sich bewegenden Teilen gelangen (15).
- Halten Sie alle Körperteile von beweglichen Komponenten fern (z. B. Spiralfeder, Hebeplatten (16).

Um die Last D abzusenken:

- Drücken Sie wiederholt Bedientaste für die schrittweise Entlastung (2), um die Last abzusenken
- Für eine hohe Präzision drücken Sie die Bedientaste für die schrittweise Entlastung (2) langsam und teilweise

Um die Hubgabel (14) abzusenken, wenn KEINE Last vorhanden ist E

- Halten Sie die Bedientaste für die vollständige Freigabe (3) gedrückt A E

HINWEIS: Gefahr von Sachschäden.

Sachschäden können auftreten, wenn die Last verrutscht oder kippt, das Produkt eine Fehlfunktion aufweist oder die No-Load Full Release Taste (3) unbeabsichtigt betätigt wird.

- Sichern Sie die angehobene Last immer.
- Überprüfen Sie vor jeder Verwendung, ob das Produkt ordnungsgemäß funktioniert.
- Drücken Sie niemals die Leerlauf-Schnellöstaste (3), wenn das Produkt unter Last steht.
- Überschreiten Sie niemals die angegebene Traglast.
- Verwenden Sie geeignete Schutzmaterialien, um Schäden an empfindlichen Oberflächen zu vermeiden.

Um die Last D abzusenken:

- Drücken Sie wiederholt Bedientaste für die schrittweise Entlastung (2), um die Last abzusenken
- Für eine hohe Präzision drücken Sie die Bedientaste für die schrittweise Entlastung (2) langsam und teilweise

Für ein schnelles Absenken der Hebearme (14) stellen Sie sicher, dass **keine Last** auf den Hebearmen liegt.

Ist eine Last vorhanden, sichern Sie diese zuerst und verwenden Sie die **Schrittweise-AbsenkTaste (2)**, um den Absenkvorgang zu kontrollieren, bis die Last vollständig abgestützt ist und das Produkt entlastet ist.

Die **No-Load-Full-Release-Taste (3)** darf erst betätigt werden, wenn die Hebearme vollständig lastfrei sind.

- Drücken und halten Sie die **No-Load-Full-Release-Taste (3)**, während Sie gleichzeitig den Griff nach unten drücken A E

Sicherungsbefestigung des Produkts

Das Produkt kann auf einer festen Oberfläche, wie beispielsweise einer Werkbank oder einer Arbeitsplatte, befestigt werden.

- Verwenden Sie drei Schrauben geeigneter Größe (nicht im Lieferumfang enthalten).
- Befestigen Sie das Produkt mithilfe der Befestigungslöcher (8).

Wartung und Instandhaltung

- Überprüfen Sie das Produkt regelmäßig auf Beschädigungen und stellen Sie sicher, dass alle beweglichen Teile ordnungsgemäß funktionieren.
- Verwenden Sie das Produkt nicht, wenn es beschädigt ist.
- Reinigen Sie die Komponenten vor und nach dem Gebrauch.
- Für eine optimale Leistung wird eine regelmäßige Schmierung empfohlen.
- Verwenden Sie ein hochwertiges Wartungsöl (z. B. Mineralöl für Druckluftwerkzeuge).
- Verwenden Sie niemals dickflüssiges Öl, Motoröl, Altöl oder silikohaltiges Öl.
- Wischen Sie die Führungsstange (17) mit einem sauberen Tuch ab.
- Tragen Sie einige Tropfen Öl auf beide schmalen Seiten der Führungsstange (17) auf, wie in der Abbildung dargestellt. F Siehe auch Video <https://bit.ly/4m3Pi8z>
- Verteilen Sie das Öl, indem Sie den Hubkörper auf der Führungsstange (17) auf und ab schieben
- Wischen Sie überschüssiges Öl mit einem sauberen, trockenen Tuch ab

Fehlerbehebung

Kein Heben möglich

Wenn Sie den Hebel (6) betätigen und sich die Hubgabel (14) nicht nach oben bewegt, sind möglicherweise die Hebeplatten (16) miteinander verklebt und müssen gereinigt werden. Lösung: Siehe Video hier https://www.youtube.com/watch?v=z_MSDbj2axc

- Entfernen Sie die Hebeplatten. (16)
- Wischen Sie die Führungsstange (17) und die Hebeplatten (16) mit einem sauberen Tuch ab
- Tragen Sie eine kleine Menge feines Wartungsöl auf die Hebeplatten (16) auf und wischen Sie sie anschließend erneut sauber
- Achten Sie beim Zusammenbau darauf, dass alle drei Hebeplatten (16) mit der abgeschnittenen Ecke in Richtung 5-Uhr-Position zeigen (stellen Sie sich vor, Sie halten das Produkt mit dem Griff vor sich).
- Geben Sie nach dem Zusammenbau einige Tropfen Öl in den Verriegelungs- und Freigabemechanismus, wie in Abb. F dargestellt.

Das Gewicht wird nicht gehalten

- Wenn sich die Hubgabel (14) beim Drücken des Bedienhebels (6) normal nach oben bewegen, aber beim Loslassen wieder nach unten fällt, oder wenn das Produkt die Last nicht halten kann, liegt das Problem bei dem Verriegelungs- und Freigabemechanismus (4).
- Bitte verwenden Sie das Produkt nicht, bis es repariert wurde.
- Bitte kontaktieren Sie uns unter vikingarm.com/support, um technische Unterstützung zu erhalten.



Viking Arm AS
Lommedalsveien 230
1353 Baerums Verk
NORWAY



@VIKINGARMTTOOLS

vikingarm.com